

**Electra ARF**  
Instruction and Operation Manual

## BVM Electra ARF

### RADIO CONTROL COMPONENTS

CONTROLS	QTY	SERVO TYPE	QTY			LEAD EXT
			Fuse	Tail	Wing	
Ailerons	2	JR 3421	1			12"
			1			"Y" Harness
					2	6"
Elevators	2	JR 3421 or DS821	1			12"
			1			"Y" Harness
Rudder	1	JR 3421	1			24"
			1			"Y" Harness
Nose Steering	1	JR 9411 or *DS821				
Flaps	1	JR 9411 or DS821	1			12"
	1	JR 9411R or DS821R	1			"Y" Harness
Mechanical Retracts	2	Spektrum A-7000	2			6"
			1			12"
			1			"Y" Harness
Battery	1	ThunderPower RX 2000 mAh 2-cell/2s 7.4v				
Regulator	1	JR 6v Voltage Regulator				

NOTE: IF EQUIPMENT OTHER THAN JR IS USED, CONSULT THAT MANUFACTURER FOR SIMILAR COMPONENTS.

DS821 servos come standard with Spektrum DX 7  
\* DS 821 must be shimmed up from tray to clear fuselage bottom.