F-86F Sabre and FJ Fury Instruction and Operation Manual

JR SERVO AND EXTENSION REQUIREMENTS

CONTROLS	QTY	SERVO TYPE	QTY	LEAD EXT
Ailerons	2	JR 3421	2	12" in wing
			1	"Y" Harness
Flaps	2	JR 3421	2	6" in wing
	1	JR MatchBox		- J
Elevators	2	JR 3121 or 3421 or 821	1	"Y" Harness
* Rudder	1	JR 3121 or 3421	1	36"
* Nose Steering	1	JR 9411		
Retract Valve	1	JR 368		
Gear Doors	1	JR 368		
Switch Harness	1	Deluxe		
Battery	1	BVM uses 2cell Lipo 1900- 2700mah		
Volt Regulator	1	Voltage Regulator 6v	1	
Gyro	1	JR - optional		

NOTE: IF EQUIPMENT OTHER THAN JR IS USED, CONSULT THAT MANUFACTURER FOR SIMILAR COMPONENTS.

NOTE: As of 2015, most of these components are obsolete and not available. Consult your R/C manufacture for current and equivalent components. High voltage systems are now prevalent.

NOTE: use of a gyro requires and extra channel.

^{*} Use of a reverse servo on one of these functions is necessary unless channels are separate and a mix is used to control the rudder and nose wheel steering.