


ELEVATOR SERVO MOUNT ADDENDUM

On page 34 of the Electra instruction manual, there is mention of two additional F7A formers that will allow the installation of a larger, standard size servo such as the Spektrum DS821. These formers are found on the 1/8" Baltic ply sheet LC028. In the event that the LC028 supplied with your kit has the extra formers but with cutouts for the mini sized servos only, you can quickly modify two of the formers to accept a larger servo.

- Measure your servo and draw the extra width and length lines directly onto the Baltic parts. Note that the length is increased towards the small lightening hole at the aft end of F7A and the width is increased towards the bottom of F7A indicated by the small tab at the front.



- Use a Drum sander to take away most of the material then a razor knife and scuff board to clean up the corners. Complete the rest of the steps as per the manual.

